

## CABEZAL HELICOIDAL

- Permite calibrar, contornar y enderezar.
- Corte progresivo preciso.
- Se suministra con guía de bolas estanca.
- Enrasador (14 x 14 x 2)  
0014.1420.00 - tornillos M5 x 8  
TORX G32.05.006.25.



MADERA

# EN847-1



## CARACTERÍSTICAS:

REF							
662.080.30	1	62	30	80	12	-	3510786628031
970.5.062.30.00	1	62	30	-	-	16	3510789700628

